

## 'EVERFLOW' TRAY DRIER



Tray Drier - 24 Trays



Tray Drier – 24 Trays

### Everflow Industrial Drying Oven (Tray Drier): ( Memmert Type ) With Digital Temperature Controller Cum Indicator And Air Circulation Fan .

- Triple walled construction on sturdy angle iron frame with outer walls of thick PCRC sheet primer painted to prevent rusting. (or) Complete SS GMP Model Tray Drier on request.
- The inner wall is made of Stainless Steel sheet / Mild Steel sheet painted with aluminum paint to withstand long duration heating cycles.
- The 100mm gap between the walls is filled with special grade glass wool for insulation.
- The front doors with sturdy hinges are also double walled with gap between the two walls compactly filled in with high-grade glass wool insulation.
- Heaters are made of Tubular Heating elements.
- Air Circulation Fans are fitted on the Back side.

### Available in following capacities

Tray Capacity : 12 Trays Standard (or) 6 Trays (Occasionally)  
24 Trays  
48 Trays  
96 Trays

---

EVERFLOW SCIENTIFIC INSTRUMENTS,  
No. 298, Kilpauk Garden Road, Kilpauk, Chennai – 600 010.  
Ph: 044-26646066, Mob: 9444259624, e-mail: [everflowin@gmail.com](mailto:everflowin@gmail.com)