

EVERFLOW HUMIDIFIER

HUMIDIFIER



HUMIDIFIER WITH DIGITAL HUMIDITY CONTROLLER AND TIMER



Humidifier is basically an Automizing Humidifier of splash plate rotating disc type. Designed to give Relative Humidity as high as upto 95% RH in enclosed areas. Humidifier is a portable unit. Capable of atomizing upto 5 Lit. of water in an hour at full Evaporation in the driest possible ambient conditions. Provided with automic float valve assembly.

SPECIFICATION:-

Type of Equipment : Cup type Atomizer
Maximum Height : 370 mm
Outer Diameter : 360 mm
Weight with Sump : 7 Kgs. (approx.)
Electrics : 230 V, 50 Hz, Single phase A.C
Connected load : 100 W
Rating : Continuous duty
Automizing Capacity : 50 ml/ min.
Available Capacity. : 5 Lit.

Suitable to work on 220 V, Single phase, 50 Hz, AC Supply

Optional Accessories:-

- ❖ Humidistat for controlling Humidity.
- ❖ Digital Humidity Controller cum Indicator
- ❖ Digital Timer
- ❖ Digital Humidity Controller cum Indicator Automatic Operation through Timer.

EVERFLOW SCIENTIFIC INSTRUMENTS

NO. 231/298, KILPAUK GARDEN ROAD, KILPAUK,
CHENNAI-600 010. Ph:044 26646066, Mob: 9444259624
e-mail : everflowin@gmail.com, www.everflowscientific.com

